




Wireless Keypad Quick Reference

Program Wireless Keypad with Receiver (APRX017)

1. Press (11) on the keypad
2. Press the learn button on the Receiver (LED will blink)
3. Press *



Changing Password

1. Press 0 key and hold it down together with *
2. Release both keys
3. Press the factory password (11)
4. Press *
5. Press new password (Maximum of eight numbers)
6. Press *
7. Re-enter the new password
8. Press *

How to use

1. Press new password
2. Press *